


1.


Caution: Keep hands on the outside of the scissor bars to avoid getting hands and fingers pinched.

After taking everything out of the carry bag, center one person on each side, in line with center scissors beam. Grasp the lower "V" at the center. Both will lift and pull out, stepping away from each other.



Pull frame out half way. Place fabric top on framework.


3.




Attach to each hook and loop corner.



4.



Pull frame completely out. Push the leg socket over the button, so that it is resting on top of the button. Do this to each leg in the up, or extended position.



Lift each leg and slide lower leg extension out until the latching button snaps into the first adjustment hole. The TLF tent will be set at the lowest upright position.





Please remember this a portable shelter so make sure whether you are setting up on concrete or on grass that you weight the canopy down.

For height or leveling adjustment, depress leg latching buttons and slide the lower leg extensions as required to latch at any of the four adjustment holes. Last, put the four ground spikes through each hole in the bottom legs to secure to ground.

## Take - Down

Depress push button on lower leg and collapse all the legs, reach under fabric at corners and push in button and pull down fitting, repeat at all four corners. Hold lower scissor bars on one side, one person on opposite side does the same, lift canopy and walk towards each other until canopy is 2/3 collapsed. Pull fabric corners off the corners and lift top off the frame, collapse the rest of the canopy to fit in bag.

